



















09 31 09 032 20



	Cyprum	09 31 09 032 20-49
	Chrom	09 31 09 032 20-00
	Platin gebürstet	09 31 09 032 20-06
	Platin	09 31 09 032 20-08
	Messing (23kt Gold)	09 31 09 032 20-09
	Dark Brass matt	09 31 09 032 20-16
	Dark Bronze matt	09 31 09 032 20-17
	Dark Chrome	09 31 09 032 20-19
	Light Gold gebürstet	09 31 09 032 20-27
	Messing gebürstet (23kt Gold)	09 31 09 032 20-28
	Schwarz matt	09 31 09 032 20-33
	Dark Brass gebürstet	09 31 09 032 20-39
	chrom satin	09 31 09 032 20-41
	Bronze gebürstet	09 31 09 032 20-42
	Champagne gebürstet (22kt Gold)	09 31 09 032 20-46
	Champagne (22kt Gold)	09 31 09 032 20-47
	Dark Platinum gebürstet	09 31 09 032 20-99



## Zugstange für Umstellung Ø 12 x 51,5 mm - Cyprum

---

ERSATZTEILE

09 31 09 032 20



## Zugstange für Umstellung Ø 12 x 51,5 mm - Cyprum

ERSATZTEILE

09 31 09 032 20