

Geberit Gateway, Firmware-Version V08

Diese Anleitung gilt für das Firmware-Update des Geberit Gateways auf die Firmware-Version V08.

Falls ein Firmware-Update zur Verfügung steht, wird dieses in der Geberit Control App mit einem orangen Warnsymbol angezeigt.

Ein Firmware-Update erfolgt entweder über die Geberit Cloud Services oder mithilfe eines USB-Sticks.

→ Siehe nächste Seite.

→ Siehe auch Systemhandbuch zu Geberit Connect, [970.746.00.0](#), Kapitel „Firmware-Update durchführen“.

Release Notes zu Firmware-Version V08

- Unterstützung der Variante des Geberit Gateways für die USA
- Unterstützung des Geberit Bus Konverters für Chicago Faucets Waschtischarmaturen und Temperatursensoren
- Unterstützung von metrischen und imperialen Einheiten

Firmware-Update mit USB-Stick

Voraussetzung

- Ein handelsüblicher USB-Stick mit FAT32-Dateisystem liegt bereit.


1 Firmware-Datei herunterladen (ca. 100 MB). Download-Link für Firmware-Version V08: https://firmwares.data.geberit.com/FwPkg_F500_Gateway_RS_08.gsi

2 Firmware-Datei (Gateway_F5_00_RS_XX.gsi) in Root-Verzeichnis des USB-Sticks kopieren. Im Root-Verzeichnis darf sich nur 1 Firmware-Datei befinden.

3 USB-Stick auf der Vorderseite des Geberit Gateways einstecken.

4 Geberit Control App mit Geberit Gateway verbinden.

- ✓ Die neue Firmware-Version wird mit einem Warnsymbol angezeigt.



5 [Firmware] öffnen und Firmware-Update starten.

- ✓ Der Fortschritt des Firmware-Updates wird mit den LEDs am Geberit Gateway angezeigt.
- ✓ Die Verbindung zur Geberit Control App wird während des Firmware-Updates unterbrochen.
- ✓ Falls die Firmware-Datei auch Firmware-Updates für Geberit Connect Endgeräte enthält, werden auch diese Updates ausgeführt.

USB-Stick erst ausstecken, wenn die weiße LED Netzanschluss am Geberit Gateway nicht mehr blinkt.

Falls beim Firmware-Update Probleme auftreten, Stromzufuhr zum Geberit Gateway für ca. 10 Sekunden unterbrechen.


Alternative: Firmware-Update mit Geberit Cloud Services

Voraussetzung

- Das Geberit Gateway ist über einen Router mit dem Internet verbunden.
- Die Geberit Cloud Services sind aktiviert.

1 Geberit Control App mit Geberit Gateway verbinden.

- ✓ Die neue Firmware-Version wird mit einem Warnsymbol angezeigt.



2 [Firmware] öffnen und Firmware-Update starten.

- ✓ Die Firmware-Datei wird heruntergeladen, und das Firmware-Update startet.
- ✓ Der Fortschritt des Firmware-Updates wird mit den LEDs am Geberit Gateway angezeigt.
- ✓ Die Verbindung zur Geberit Control App wird während des Firmware-Updates unterbrochen.
- ✓ Falls die Firmware-Datei auch Firmware-Updates für Geberit Connect Endgeräte enthält, werden auch diese Updates ausgeführt.

Geberit Gateway, firmware version V08

These instructions apply to the firmware update of the Geberit Gateway to firmware version V08.

If a firmware update is available, this is displayed in the Geberit Control app by an orange warning sign.

Firmware for the Geberit Gateway is updated either through Cloud Services or using a USB flash drive. → See next page.

→ See also system manual on Geberit Connect, [970.746.00.0](#), “Updating firmware” section.

Release notes for firmware version V08


- Support for the US model of the Geberit Gateway
- Support for the Geberit bus converter for Chicago Faucets washbasin taps and temperature sensors
- Support for metric and imperial units

Firmware update with USB flash drive

Prerequisite

- A standard USB flash drive with FAT32 file system is available.

- 1 Download firmware file (approx. 100 MB).
Download link for firmware version V08:
https://firmwares.data.geberit.com/FwPkg_F500_Gateway_RS_08.gsi
- 2 Copy the firmware file (Gateway_F5_00_RS_XX.gsi) to the root directory of the USB flash drive. Only 1 firmware file is allowed to be located in the root directory.
- 3 Insert the USB flash drive into the front side of the Geberit Gateway.
- 4 Connect the Geberit Control app to the Geberit Gateway.
 - ✓ The new firmware version is displayed with a warning sign.



- 5 Open [firmware] and start the firmware update.
 - ✓ The progress of the firmware update is indicated by the LEDs on the Geberit Gateway.
 - ✓ The connection to the Geberit Control app is interrupted during the firmware update.
 - ✓ If the firmware file also contains firmware updates for Geberit Connect end devices, these updates will be also performed.

Only unplug the USB flash drive once the white mains connection LED on the Geberit Gateway stops flashing.


If problems occur during the firmware update, disconnect the power supply to the Geberit Gateway for approx. 10 seconds.

Alternative: Firmware update with Geberit cloud services

Prerequisite

- The Geberit Gateway is connected to the internet via a router.
- The Geberit Cloud Services are activated.

- 1 Connect the Geberit Control app to Geberit Gateway.
 - ✓ The new firmware version is displayed with a warning sign.



- 2 Open [firmware] and start firmware update.
 - ✓ The firmware file is downloaded and the firmware update starts.
 - ✓ The progress of the firmware update is indicated by the LEDs on the Geberit Gateway.
 - ✓ The connection to the Geberit Control app is interrupted during the firmware update.
 - ✓ If the firmware file contains also firmware updates for Geberit Connect end devices, these updates will be also implemented.