





Ersatzteilliste

#	Beschreibung	Art.-Nr.	PG
1	Griffhebel	80.433205.2.09	12
2	Inbusschraube	80.131031.1.09	1
3	Glockenkappe	80.101000.2.09	7
4	Konterring für Kartusche	80.517059.1.09	4
5	Keramik-Kartusche	80.102619.2.09	7
6	Perlator Eco M21x1	80.101422.6.09	7
7	Befestigung Satz	80.016008.2.09	4
8	Flexschlauch	80.101708.2.09	6